

Quick Installation Guide

Wireless USB Adapter

English	Deutsch	Français	Español
Italiano	Български	Čeština	Dansk
Ελληνικά	Eesti	Suomi	Hrvatski
Magyar	Қазақша	Lietuvių kalba	Latviski
Nederlands	Norsk	Polski	Português
Română	Русский	Slovenčina	Slovenščina
Srpski	Svenska	Türkçe	Україна
عربي، غة لال	日本語	한국어	Indonesia
ភាសាខ្មែរ	Tiếng Việt	中文（简体）	中文（繁體）

NEED TECH HELP?	810600626
 www.cudy.com	 support@cudy.com
 www.cudy.com/download	
Support: For technical support, the user guide and more information, please visit: https://www.cudy.com/support	

English

1 Insert the USB adapter into a USB port (USB 3.0 or higher for optimal performance) on the computer.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

- If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.
- If any more problem, feel free to contact support@cudy.com.

Eesti

1 Sisestage USB-adapteri arvuti USB-porti (optimaalse jõudluse tagamiseks USB 3.0 või uuem).

2 USB-draiv avaneb või valige See arvuti → USB-draiv. Topeltklõpsake failil **USB Adapter.exe** ja seejärel klõpsake draiveri installimiseks nuppu **Install**.

3 Looge ühendus traadita võrguga.

Märkus:

- Kui see ei tööta, külastage draiveri allalaadimiseks aadressi www.cudy.com/wu, installige see ja proovige seejärel uuesti WiFi-ühendust luua.
- Kui teil on veel probleeme, võtke julgelt ühendust aadressil support@cudy.com.

Polski

1 Podłącz adapter USB do portu USB (USB 3.0 lub nowszego dla optymalnej wydajności) w komputerze.

2 Wyświetli się dysk USB lub przejdź do Ten komputer → Dysk USB. Kliknij dwukrotnie plik **USB Adapter.exe**, a następnie kliknij **Install**, aby zainstalować sterownik.

3 Połącz się z siecią bezprzewodową.

Uwaga:

- Jeśli to nie zadziała, odwiedź stronę www.cudy.com/wu, aby pobrać sterownik, zainstalować go, a następnie ponownie spróbować połączyć się z siecią Wi-Fi.
- W przypadku dalszych problemów skontaktuj się z nami pod adresem support@cudy.com.

Україна

1 Вставте USB-адаптер у USB-порт (USB 3.0 або вище для оптимальної продуктивності) на комп'ютері.

2 З'явиться USB-накопичувач або перейдіть до Цей ПК → USB-накопичувач. Двічі клацніть **USB Adapter.exe**, а потім натисніть **Install**, щоб установити драйвер.

3 Підключіться до бездротової мережі.

Примітка:

- Якщо це не працює, відвідайте веб-сайт www.cudy.com/wu, щоб завантажити драйвер, інсталийте його та знову спробуйте підключитися до Wi-Fi.
- Якщо виникнуть додаткові проблеми, не соромтеся зв'язатися з support@cudy.com.

1 Insert the USB adapter into a USB port (USB 3.0 or higher for optimal performance) on the computer.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless net-work.

Note:

If it doesn't work, visit www.cudy.com/wu to download the driver, install it and then try Wi-Fi connectivity again.

If any more problem, feel free to contact support@cudy.com.

2 USB Drive pops up or go to This PC → USB Drive. Double-click the **USB Adapter.exe** and then click **Install** to install the driver.

3 Connect to the wireless

Operating Frequency (Maximum transmitted power) (EN)